



BOWSER - LOST WAX BRASS PARTS


<p>A</p> <p>90011 Air hose</p> <p>90018 Air & signal hoses-tender</p> <p>90419 Air Tank</p> <p>90460 Air Tank</p> <p>90364 Strainer air compressor</p> <p>90387 Air pump</p> <p>90485 Air compressor</p> <p>90416 Air compressor left</p> <p>90417 Air compressor right</p> <p>90326 Air compressor</p> <p>90363 Air compressor</p> <p>90306 Air compressor</p> <p>90341 Dual air compressor</p> <p>90456 Air compress bottom</p> <p>90457 Air compressor top</p> <p>90372 Air tank</p> <p>90436 Air Tank</p> <p>90461 Air line, air compressor</p>	<p>G</p> <p>91015 Generator</p> <p>90392 Generator</p> <p>90379 Generator Bracket</p> <p>90418 Generator on bracket</p> <p>90443 Generator</p> <p>90361 Generator</p>		
<p>B</p> <p>90031 Bell</p> <p>90032 Bell bracket</p> <p>90321 Bell</p> <p>90301 Bell USRA Mt.</p> <p>90424 Bell</p> <p>90061 Brake shoes, Pr.</p> <p>90310 Bracket brake cylinder</p> <p>90323M-1 Builder's plate</p> <p>90337 M-1a Builder's plate</p>	<p>H</p> <p>91016 Headlight</p> <p>90432 Headlight T-1</p> <p>90441 Headlight A-5</p> <p>90442 Headlight Bracket</p> <p>90041 Headlight Bracket</p> <p>91018 Headlight Bracket</p> <p>90481 Long Handrail Stanchion</p> <p>90446 Dome Hatch</p> <p>90491 Dome Hatch</p> <p>90431 Sander valve access hatch</p> <p>90479 Cab hatch</p> <p>90449 Cab Hatch</p> <p>90425 Cab Hatch</p> <p>90308 Cab Hatch</p> <p>90428 Sand Dome Hatch</p>		
<p>C</p> <p>90330 Coupler lift bar stanchions</p> <p>90433 Coupler lift bar stanchions</p> <p>90459 Cab step</p> <p>90493 Coal pusher</p> <p>90476 Crosshead guide, A-5</p>	<p>I</p> <p>90315 Inspection Lid</p> <p>90305 Injector Bracket</p> <p>90331 Injector Bracket</p> <p>90092 Injector, left</p> <p>90093 Injector, right</p> <p>90313 Injector, left</p> <p>90314 Injector, right</p> <p>90482 Injector, left</p> <p>90483 Injector, right</p>		
<p>D</p> <p>90437 Tender Deck Drain</p>	<p>E</p> <p>90448 Exhaust muffler with pipes</p>	<p>J</p> <p>90367 Round junction box</p> <p>90444 Junction box</p>	<p>M</p> <p>90328 Marker light</p> <p>90329 Marker light, angled</p> <p>90467 Marker lights angled</p>
<p>F</p> <p>90488 Flag Holder</p> <p>90365 Feedwater Pump</p> <p>90357 Feedwater</p>		<p>L</p> <p>90398 Lubricator</p> <p>90413 Mech Lubricator Left, small base</p> <p>90414 Mech lubricator right, small base</p> <p>90415 Mech lubricator w large base</p> <p>90420 Double Mechanical Lubricator</p> <p>90343 Lubricator</p>	

BOWSER - LOST WAX BRASS PARTS

P




P




R



S



T



BOWSER - LOST WAX BRASS PARTS

V



90320 Check valve



90358 Check valves with pipes



90411 Cylinder relief valve



90412 Cylinder drain valves



90427 Pop Valves



90362 Sander valve



90111 Pr. Sander valves



90385 Globe valve



90494 Starter valve

W



90438 Water scoop



90489 Walk step



90447 Pop, whistle and valve



90360 or 90311 Whistle



90322 Wind deflector



90450 Wind deflector



90426 Wind deflector