



1302 Jordan Ave. P.O. Box 322 Montoursville PA 17754 1-570-368-2379

WWW.BOWSER-TRAINS.COM

Bowser Executive Line Sound Equipped DS4-4-1000

Quick Start Guide

Please go to www.LokSound.com for a complete user manual

You have just purchased a Top of the Line Locomotive with one of the most State of Art Digital Sound Decoders on the Market. With nothing more than your Digital Command Station you have the option of 16 separate horns, 2 bells, and 2 brakesqueals. All changeable by one CV. No booster is needed! Each individual sound has a separate volume control, and up to 8 sounds can be played at one time! Not only that, but as new sounds become available and firmware gets updated, you can at anytime, hook up to our famous LokProgrammer and update your decoder! Along with outstanding sound, ALL LokSound decoders give you the benefit of the Industry Leading ESU Motor control. You'll see the difference instantly as the engine smoothly accelerates across your pike! Don't forget you also have the option to use one of our MANY lighting effects on any one of your 6(!) function outputs!

| Technical data LokSound Select Decoder | |
|---|--|
| Operational modes: | |
| NMRA/DCC with 14, 28, 128 speed steps | |
| 2-digit (short) or 4-digit (long) addresses | |
| Analog DC (Dual mode, de-selectable) | |
| Automatic recognition of operational mode | |
| Supports ALL NMRA programming modes | |
| Power: | |
| Runs all DC and coreless motors | |
| Silent, safe 31,25 kHz pulse width frequency BEMF | |
| Motor output overload protected | |
| Function outputs: | |
| 6 outputs | |
| 250 mA load per output | |
| Outputs short-circuit protected | |
| Sound: | |
| Audio amplifier: 2W @40ohms load | |
| Speaker impedance 4-8 Ohms | |
| Memory Capacity 32MBit | |
| 8 Sound Channels, All playable at once! | |
| Over 20 different sounds! | |
| Dimensions: | |
| 1.02 x 0.62 x 0.18 inch (25.5 x 15.5 x 4.5 mm) | |

| Default Function Assignments | |
|------------------------------|--------------------------------------|
| Function key | Effect |
| F0 | Directional Headlights |
| F1 | Bell |
| F2 | Playable Airhorn |
| F3 | Coupler Clank |
| F4 | Warm Start (Cold Start if F4 is off) |
| F5 | Short Air Let Off |
| F6 | Spitter Valve |
| F7 | Switching Mode |
| F8 | Prime Mover Sound On/Off (MUTE) |
| F9 | Manual Notching Up |
| F10 | Manual Notching Down |
| F11 | Brake Set/Release |
| F12 | Dimmer (Headlights) |
| F13 | Compressor |
| F14 | Sanding Valve |

| Diesel Prime Movers | | | |
|--|-------------|--------------------|---------|
| Prime Mover name | CV 48 value | | |
| There is only one Baldwin DS4-4-1000 Prime Mover sound on this decoder. Please use a Value of 0 for this part of the CV48 calculation. | | | |
| Diesel Decoders Airhorns | | 16 to choose from! | |
| Airhorn name | CV 48 value | | |
| Airhorn Nathan K5LA | | 0 | |
| Airhorn Nathan K3L | | 1 | |
| Airhorn Nathan M5 | | 2 | |
| Airhorn Nathan P3 | | 3 | |
| Airhorn Nathan P5A | | 4 | |
| Airhorn Baldwin Single Chime | 5 | 5 | Default |
| Airhorn Leslie A200 | | 6 | |
| Airhorn Leslie S3L | | 7 | |
| Airhorn Leslie SST | | 8 | |
| Airhorn Leslie M3 | | 9 | |
| Airhorn Wabco A2 | | 10 | |
| Airhorn Wabco E2 | | 11 | |
| Airhorn Holden S3LR | | 12 | |
| Airhorn Nathan Holden M3H | | 13 | |
| Airhorn Fairbanks Morse Trainmaster | | 14 | |
| Airhorn Nathan single Chime | | 15 | |
| Diesel Decoders Bell Types | | 2 to choose from! | |
| Bell Type | CV 48 value | | |
| Slow Bell | 0 | 0 | Default |
| Fast Bell | | 64 | |
| Diesel Decoders Brake Squeals | | 2 to choose from! | |
| Brake Squeal Version | CV 48 value | | |
| Brake Squeal Version #1 | 0 | 0 | Default |
| Brake Squeal Version #2 | | 128 | |

Extended Addressing
Most Command Stations will give you the option to enter a 4 Digit Extended Address. Please refer to your Command Station's Manual for guidance as to how to do this. If your command Station does not have this feature a full list of values and instructions are available on line at www.loksound.com

Start Delay
While pulling a train a Prototype Locomotive will not move until the Prime mover has worked up enough power to provide the proper amount of electricity to the traction motors. For this reason when the LokSound Select sound is idling and you turn up the throttle, the locomotives begins to move only after the Diesel engine has reached notch1. Although this behavior is very prototypical, one might not like it because it causes some delay. You can disable this startup delay by simply Changing CV124 to a value of 0. This will cause the LokSound Select decoder to immediately start moving when the throttle is turned up. However, the start up sound will not be prototypically synced with the motion anymore.

Sound on/Sound Off (F8 Operation)
You will notice quickly that F8 button will work differently than what you may be used to. This is done for two reasons. First so that you can hear both the start and Shut down sequences without any CV changes. Also so that upon power up the drain on your command station is not as great. Sound decoders draw quite a bit of power upon start up. Having the sound off initially when the layout is powered up is a much more efficient way on doing things. This can save your command station from an early demise! You may be used to other manufacturers who do this backwards. If you prefer you can easily reverse this feature. Simply Change CV32 to 2, then CV403 to 32. Please note also that F8 only controls the prime mover sounds. On a real engine, as long as there is air, the bell and the horn will work when the prime mover is off!

| Diesel sound Volume Control table | | | |
|-----------------------------------|-----|---------|---------|
| Function (Diesel) | CV | Range | Default |
| Master volume control | 63 | 0 - 192 | 192 |
| Diesel Volume Control | 259 | 0 - 128 | 128 |
| Horn Volume Control | 275 | 0 - 128 | 128 |
| Bell Volume Control | 283 | 0 - 128 | 99 |
| Coupler Sound Volume Control | 291 | 0 - 128 | 128 |
| Turbo Volume Control | 419 | 0 - 128 | 128 |
| Air Compressor Volume Control | 307 | 0 - 128 | 77 |
| Brake Set / Brake Release | 347 | 0 - 128 | 128 |
| Sanding valve Volume Control | 355 | 0 - 128 | 128 |
| Short Air Let Off Volume Control | 363 | 0 - 128 | 128 |
| Spitter Valve Volume Control | 371 | 0 - 128 | 128 |
| Random sounds | 451 | 0 - 128 | 128 |

BE SURE CV 32 IS SET TO 1 BEFORE CHANGING CVs 257-511

Decoder-Reset
Write value 08 into CV 08.
From time to time you may have the need to reset the decoder in your new Locomotive. Setting CV08 to a value of 08 with accomplish this. Be aware though that all user settings will be set back to factory defaults with this process.

Sound Choices
This Factory equipped LokSound Digital Sound Decoder was built specifically to be correct for the Prototype of the model. You may find however that you would like different Sounds. All sounds can be changed with CV48 and your Command Station. CV 48 is calculated by adding the Prime mover, the horn, the Bell, and the brake squeal selection you would like in your model. By adding your choices from the charts above you will arrive at the value to put in CV 48.

Default Example:
Prime Mover = 0
Airhorn = 5
Bell = 0
Brake Squeal = 0

Total = 5
CV48 Value = 5

A full PDF Manual can be found at www.LokSound.com
Please refer to the LokSound Select Manual.

As a Reference NO BOOSTER is needed for programming.